

FOLLOW THESE CLEANING GUIDELINES TO CLEAN ANY AIPHONE INTERCOM

STEP-BY-STEP CLEANING INSTRUCTIONS






DO NOT get liquids inside the unit. DO NOT directly spray cleaning product on the unit.

DO use wet wipes, a sprayed cloth, or dampened cloth (no excess moisture)



DO use NON-ABRASIVE cleaning wipes or cloths.





Wipe the surfaces with the appropriate wipes or cloths and approved cleaning products and allow them to dry.

THE DEVICE



alcohol (>70%), undiluted bleach, or ammonia.

STEP-BY-STEP DISINFECTING INSTRUCTIONS





- DO USE
- Clorox® Disinfecting Wipes
 Lysol® Clean & Fresh
- Clorox® Healthcare Bleach Germicidal Wipes
- Clorox[®] Commercial Solutions Hydrogen Peroxide Cleaner Disinfectant Wipes
- Lysol[®] Clean & Fresh
 Multi-Surface Cleaner
 (20% cleaner solution to water ratio)
- Purell[®] Professional Surface
 Disinfectant Wipes
- Sani-Cloth[®] Prime Germicidal Disposable Wipes
- Lonza® Disinfectant Wipes

- Isopropyl Alcohol at concentration > 70%
- Methyl Alcohol or Ethyl Alcohol at concentration > 35%

93

- Thinner or benzine
- Strong alkali lyes
- Strong solvents
- Acids
- Detergents with fluoride
- Detergents with abrasives
- Ammonia at Detergents with concentration > 1.6%
- Abrasive cleaners
- Abrasive sponges
- Steel blades
- Cloth with steel threads

More information from the Center of Disease Control (CDC) on disinfecting procedures for Coronavirus Disease 2019 (COVID-19) can be found here:

https://www.cdc.gov/coronavirus/2019-ncov/community/home/cleaning-disinfection.html

More information from the Environmental Protection Agency (EPA) on recommended disinfectants for Coronavirus Disease 2019 (COVID-19) can be found here: https://www.epa.gov/pesticide-registration/list-n-disinfectants-use-against-sars-cov-2

CAIPHONE